

# FP-1 Supported iPods

Models and Features

Model	Generation	Capacity	FP-1 Music	FP-1 Video/Photos
<b>Classic</b>	1st	5/10 GB	N/A	N/A
	2nd	10/20 GB	N/A	N/A
	3rd	10/15/20/30/40 GB	N/A	N/A
	4th	20/40 GB	N/A	N/A
	5th	Photo: 30/40/60 GB	•	•
		Color: 20/60 GB	•	•
<b>Mini</b>	6th	80/120/160 GB	•	N/A
	1st	4/6 GB	•	N/A
<b>Nano</b>	2nd	4/6 GB	•	N/A
	1st	1/2/4 GB	•	N/A
<b>Shuffle</b>	2nd	2/4/8 GB	•	N/A
	3rd	4/8 GB	•	N/A
	4th	4/8/16 GB	•	N/A
	1st	512 MB / 1 GB	N/A	N/A
<b>Touch</b>	2nd	1/2 GB	N/A	N/A
	1st	8/16/32 GB	•	N/A
		8/16/32 GB	•	N/A

- - Supported
- N/A - Unsupported

**Note:** FP-1 is able to access music on all iPod models featuring a color display.

For more information visit: [http://en.wikipedia.org/wiki/List\\_of\\_iPod\\_models](http://en.wikipedia.org/wiki/List_of_iPod_models)

### Videos/Photos:

In order to access video and photos on supported iPod models you must enable the iPod's A/V output (see below) and place the FP-1 in an A/V pass-thru mode by pressing the MOVIE or PHOTOS button on the FP-1 remote. Selecting either a video or photo slideshow must be performed using the iPod's controls. This cannot be performed using the FP-1 factory IR remote.

### Enabling the iPod's A/V output:

```

Videos>
  Video Settings>
    TV Out>On
    TV Signal>NTSC/PAL
    Widescreen>On/Off

Photos>
  Slideshow Settings>
    TV Out>On
  
```